

Logistic Regression in R

Ryan Dickson, *PhD*
Feb 4th, 2016

EDNS-RAD



EDNS-RAD

An evaluation of radioisotope detector performance for first-responder use.



Sources

Nuclide	Activity
Cs-137	0.191 mCi
Ba-133	0.092 mCi
Co-60	0.086 mCi
I-125	0.441 mCi
Gd-153	0.138 mCi



Identification

- Time-to-Identification
- Isotopes(s)
- Confidence Levels



Descriptive Range

Low

Medium

High

Confidence Range

40 - 64

65 - 84


85 - 100

Identification

- Time-to-Identification
- Isotopes(s)
- Confidence Levels

CL1 →

CL2 →



Descriptive Range

Low

Medium

High

Confidence Range

40 - 64

65 - 84

85 - 100

ID results


119 Trials: 54 Single Isotope; 65 Two isotope
Time-to-Identification typically under 5 minutes

clearly not big data

Zee Data

Source	TTI (s) tot	ID	CL	bolus	num	correct
Cs137	213	Cs137	93	0	0	1
Cs137	210	Cs137	95	0	0	1
Cs137	210	Lu177	41	0	1	0
Cs137	221	Cs137	93	0	0	1
Cs137	221	Pb214	44	0	1	0
Cs137	183	Cs137	92	3	0	1
Cs137	183	Se75	41	3	1	0
Cs137	185	Cs137	90	3	0	1
Cs137	185	Cr51	46	3	1	0
Ba133	90	Ba133	87	0	0	1
Ba133	90	I131	48	0	1	0
Ba133	100	Ba133	86	0	0	1
Ba133	100	I123	53	0	1	0

Interceptor ID Accuracy




Logistic Regression


GLM - generalized linear model
predicts a categorical dependent
variable

For this case, the
binary result for correct
identification.

To the whiteboard...




Interceptor ID Accuracy




ID Results

1st Isotope



2nd Isotope



ID results

- 119 Trials: 54 Single Isotope; 65 Two isotope
- Time-to-Identification typically under 5 minutes
- Primary Isotope Correct **96% of the time**
- Secondary Isotope was Problematic**
 - Correct less than 10% of time in single isotope case
 - Only correct 42% of time in two isotope case
- Primary analysis question is one of *confidence***
- Gd-153 identified as Sm-153, limits of device library

ID results

- 119 Trials: 54 Single Isotope; 65 Two isotope
- Time-to-Identification typically under 5 minutes
- Primary Isotope Correct **96% of the time**

Descriptive Range	Confidence Range	ID1 Accuracy	ID2 Accuracy
Low	40 - 64	68% (n=19)	19% (n=105)
Medium	65 - 84	100% (n=80)	78% (n=14)
High	85 - 100	100% (n=20)	NA (n=0)

- Gd-153 identified as Sm-153, limits of device library

Further Reading and Links

[Example with apache II scores for predict sepsis](#)

[Generalized_linear_model](#)

[Readmission Risk and Pneumonia](#)

Discussion of Capability

- Can set higher minimum ID Time, ~5 min
- Dose-rate measures hazard
- Mis-identification concerns.
 - One isotope listed is medical, one is not? Which is truly present?
- Operator demands
 - User Unattended mode mostly works
 - Ceiling position difficult to observe
- Blind to alpha and beta emitters (no easy solution)


IAEA Emergency Guidelines

- Decontaminate using fire hoses, scrub brushes and detergents.
- Do not delay/interfere with the response to remove/replace contaminated filters.
- Re-survey the contaminated areas and perform the following:


If ambient dose rate at 10 cm is:	Perform the action:
> 1 $\mu\text{Sv/h}$ and <10 $\mu\text{Sv/h}$	Use for response activities only.
> 10 $\mu\text{Sv/h}$ and <100 $\mu\text{Sv/h}$	Use for critical response activities only (e.g. needed for transport of injured). The use of these items must be controlled. Once their use is no longer critical they should be isolated. The people who use this equipment must follow Instruction 2 and take all reasonable action to reduce their skin exposure (wear gloves) and limit use to less than a few hours.
> 100 $\mu\text{Sv/h}$	Isolate and use only with radiological assessor approval.

(7) Only release potentially contaminated vehicles and equipment for general use when assessed by a radiological assessor and found to meet national criteria.


Backup and Additional Info



Survey Results




- Higher count-rate than lab studies
- Power-law trend similar
- More pronounced for Ba-133
- Smaller environment



ID results

- 119 Trials: 54 Single Isotope; 65 Two isotope
- Time-to-Identification typically under 5 minutes
- Primary Isotope Correct 96% of the time
- Secondary Isotope was Problematic
 - Correct less than 10% of time in single isotope case
 - Only correct 42% of time in two isotope case
- Primary analysis question is one of ***confidence***


Interceptor Confidence Levels




CL1 \geq CL2 by
definition

Overlap in the 1st
and 4th quartiles

Single Isotope Trials



Two Isotope Trials



Only Correct Events

